


Air cooled water chilled for outdoor installation

Installation use and maintenance manual



Dear Customer,

We congratulate you on choosing these product.

Clivet is being working for years to offer systems able to assure the maximum comfort for long time with high reliability, efficiency , quality and safety. The target of the company is to offer advanced systems, that assure the best comfort, reduce the energy con-sumption, the installation and maintenance costs for all the life-cycle of the system.

With this manual, we want to give you information that are useful in all the phases: from the reception, to the installation and use until the disposal so that a system so advanced offers the best procedure of installation and use.

Best regards and have a nice reading !

CLIVET Spa

INDEX

1	General	4
2	Reception	8
3	Positioning	9
4	Water connections	10
5	Electrical connections	12
6	Start-up	22
7	Regulation	26
8	Maintenance	41
9	Technical information	43
10	Disposal	49
11	Residual risks	50

The data contained in this bulletin is not binding and may be changed by the manufacturer without prior notice.


Reference technical bulletin : BT07F014GB-09


1 - GENERAL

1.1 MANUAL


The manual provides correct unit installation, use and maintenance.

Pay particular attention to:

 Warning identifies particularly important operations or information .


 Prohibited operations that must not be carried out, that compromise the operating of the equipment or may cause damage to persons or things.

- It is advisable to read it carefully so you will save time during operations.

 • Follow the written indications so you will not cause damages to things and injuries people. The preliminary information must be read prior to carrying out any of the following operations.

1.2 GENERAL INSTRUCTIONS

Preliminaries

 The positioning, hydraulic system, refrigerating, electrics and the channelisation of the air must be determined by the system designer in accordance with local regulations in force.

Only qualified personnel can operate on the unit, as required by the regulation in force.

Using the unit in case of breakdown or malfunction :


- voids the warranty
- may compromise the safety of the machine
- may increase time and repair costs.

Follow local safety regulations. .

Keep packing material out of children's reach it may be dangerous. .

Recycle and dispose of packing material in conformity with local regulations. .

Risk situations


 The unit has been designed and created to prevent injuries to people.

During designing it is not possible to plane and operate on all risk situation.

Read carefully "Residual risk" section where all situation which may cause damages to things and injuries to people are reported.


Installation, starting, maintenance and repair required specific knowledge; if they are carried out by inexperienced personnel, they may cause damages to things and injuries people.

Intended use


 Use the unit for cooling water or a water and glycol mix for air-conditioning only, within limits defined in the technical bulletin and on this manual..

Any use other than intended does not involve the manufacturer in any commitment or obligation. .

Installation


 Verify that the electrical line characteristics are in compliance with data quotes on the unit serial number label.

Maintenance

 Plan periodic inspection and maintenance in order to avoid or reduce repairing costs.

Turn the machine off before any operation.

Modification

 All unit modifications will end the warranty coverage and the manufacturer responsibility. .


Breakdown/Malfuction

Disable the unit immediately in case of breakdown or malfuction. .

Contact a constructor certified assistance service.

Use original spares parts only.

User training

 The installer has to train the user on :


- start-up / shutdown;
- set points change;
- standby mode;
- maintenance;
- what to do / what not to do in case of breakdown.

Data update

Continual product improvements may imply manual data changes .

Visit manufacturer web site for updated data.

1.3 INDICATIONS FOR THE USER

 Keep this manual with the wiring diagram in an accessible place for the operator.

Note the unit lable data so you can provide them at the assistance centre in case of intervention (see "Unit identification" section).

Provide a machine notebook that allows any interventions carried out on the machine to be noted and tracked making it easier to suitably note the various interventions and aids the search for any breakdowns.

In case of breakdown or malfunction:

- immediately deactivate the unit .
- contact a assistance service centre authorized by the manufacturer.

 • use original spares parts only

Ask the installer to format on:

- start-up / shutdown;
- set points change;
- standby mode;
- maintenance;
- what to do / what not to do in case of breakdown.

1 - GENERAL

1.4 UNIT IDENTIFICATION

Serial number label

The serial number label is positioned on the unit and allows to identify all the unit features.



It has not to be removed for any reason.

It reports the regulations indications such as:

- machine type, exmple:
 - Series → **WSAT-XEE**
 - Size → **82....302**
- serial number
 - 12 characters → **Axxxxxxxxxx**
- year of manufacture
- wiring diagram number
- electrical data
- manufacturer logo and address .

Serial number

It identifies uniquely each machine.

It identifies specific spare parts for the machine.

Assistance request

Note data from the serial number label and write them in the chart on side, so you will find them easily when needed.


In case of intervention you have to provide data.

Serie
Size
Serial number
Year of manufacture
Wiring diagram

1.5 PRINCIPLE OF OPERATION

SUMMER: the cooling cycle allows the transfer of excess indoor heat to the external environment.

1. The compressor compresses the refrigerant gas, placing it at high pressure and high temperature.
2. In the external coil, the refrigerant is cooled, and the heat is released into the environment by means of the fan. This is why the coil needs to be kept clean and free of obstacles.
3. When it cools, the refrigerant becomes liquid.
4. The expansion valve causes a sudden drop in the pressure of the refrigerant, which becomes very cold as its volume increases.
5. In the exchanger, the refrigerant evaporates and absorbs the heat from the water that returns to the system, cooling it.



1.6 ACCESSORIES

VERSIONS OPTIONS

D Partial energy recovery

B Water low temperature

- Free-cooling: not required

FCD Direct FREE-COOLING

CONFIGURATIONS

DSPB Double set point for water low temperature

CREFB Device for reduction of fan consumption

ECOBREEZE

REFRIGERANT CIRCUIT

CCCA Copper / aluminium condenser coil with acrylic lining

CCCA1 Copper / aluminium condenser coil with Fin Guard treatment (Silver)

MHPX High and low pressure gauges

OHP Operation in heat pump

OHO Heat-only function

HYDRAULIC CIRCUIT

- Hydronic group utility side: not required

1PUS Standard pump

1PUR Single-pump with reduced available head

1PUM Single-pump with larger available head

2PUS Standard double pump

2PUR Double pump with reduced available head

2PUM Double pump with larger available head

IFWX Water steel mesh strainer

ACC1 Teflon steel storage device

SYSTEM ADMINISTRATORS

CMMBX Serial communication module to supervisor (MODBUS)

CMSC9 Serial communication module to Modbus supervisor

CMSC7 MODBUS/LON WORKS serial converter kit

ELECTRIC CIRCUIT

RCMRX Remote control via microprocessor control

PCDWX Daily and weekly programming clock

PM Phase monitor

PMX Phase monitor

SFSTR4N Disposal for inrush current reduction, for unit 400/3/50+N

PFCP Power factor correction capacitors (cosfi > 0.9)

CLSE Free contacts for alarm

SCPX set-point compensation with outdoor air temperature probe

SCP3X Set point compensation according to the outside enthalpy

INSTALLATION

AMRX Rubber antivibration mounts

PGCEX Coil protection grilles external air side

1.7 FREE-COOLING

ATTENTION:

The unit **WSAT-XEE 122** in Free-Cooling version, is built on mobile sizes **162-182**, the same for the size **222**, that is developed on Movable **262-302**.

The weights of the units vary in reference to what is present in this document.

FREE-COOLING When the temperature of the fresh air is lower than the temperature of the return water of the system, the free-cooling version lets you recover cold from the external environment, reducing the work of the compressors all the way down to nothing.

The Free-Cooling unit differs mechanically from the standard unit due to the addition of a 3-way valve and a special finned packaged air/water heat exchanger. Seasonal weather conditions cause the unit to operate in one of three different modes:

- **Summer mode.**
- **Spring/autumn mode.**
- **Winter mode.**

For the unit to work correctly in all situations, in complete safety, and with complete recovery of cooling power, the use of a modern, sophisticated microprocessor is required, which monitors a number of parameters (especially temperature and pressure) for the fresh air, gas and water circuit.

The main difference between summer mode and the other modes is the position of the 3-way valve.


In the summer, the valve is positioned so that it bypasses the Free Cooling coils, which in the other seasons are involved in cooling the solution.

1 - GENERAL

FREE-COOLING SUMMER MODE

Cooling of the solution is ensured by the refrigerating cycle with operation of the compressors (C) as in a traditional chiller - as you can see in the figure, the Free-Cooling (Bh) coils are not involved.

Legend	SL = liquid waring light
Ae = fresh air	V3 = three-way valve
Bc = condensing coil	Ve = expansion valve
Bh = water coil	VA = cock on the suction line
C = scroll compressor	Vm = cock on the return line
E = plate evaporator	Wi = water inlet
F = filter dryer	Wo = water outlet
Fa = fan	




FREE-COOLING SPRING-AUTUMN MODE

Energy savings variable between 0 and 100%, based on the temperature difference between fresh air and the system request

If the unit detects that the fresh air temperature (Ae) is suitable:

- 1) it inverts the position of the 3-way valve (V3), forcing the solution to travel through the Free-Cooling coils (Bh) before reaching the evaporator (Ev);
- 2) it sets the fans (Fa) at maximum speed to obtain maximum cooling of the solution from the fresh air;
- 3) the solution thus undergoes an initial cooling which is free and natural;
- 4) the remaining cooling is provided by the refrigeration cycle, with compressors in stepped operation (power absorbed proportional to the degree of stepping);


If the temperature of fresh air increases, the microprocessor will automatically revert operation to summer mode, ensuring the same conditions requested by the user.



FREE-COOLING WINTER MODE

The three way valve (V3) is in the same position as in the previous case;

- the temperature of the fresh brings the solution at the outlet of the Free-Cooling coils (Bh) to the temperature required for use;
- the microprocessor control completely deactivates all compressors (C), providing all cooling power at no cost, as opposed to standard units;
- if the difference between the temperature of the fresh air (Ae) and that required for use is such that the temperature of the solution at the outlet of the Free-Cooling coils (Bh) drops below the set point required for use (which does not compromise unit safety, because of the glycol in the solution), the microprocessor modulates fan speed (Fa), turning them off if necessary. When the fans are off, if the temperature (Wo) continues to drop, the 3-way valve (V3) positions itself as in summer operation, changing to digital and allowing the set point to be maintained.



2- RECEPTION

2.1 PRELIMINARY INFORMATION



Operate in compliance with safety regulations in force .

For detailed information (dimensions, weight, technical characteristics etc.) please refer to the "Technical information" section.

Use single protection devices : gloves, glasses ecc. .

2.2 DELIVERY CONTROL



Before accepting the delivery you have to check:

- That the unit hasn't been damaged during transport.
- Check that the materials delivered correspond with that indicated on the transport document comparing the data with the identification label 'A' positioned on the packaging.

In case of damage or anomaly:

- Write down on the transport document the damage you found and quote this sentence: "Conditional acceptance — clear evidence of deficiencies/ damages during transport".
- Contact supplier and the carrier by fax and registered mail with advice of receipt.

Any disputes must be made within the 8 days following the delivery. Complaints after this period are invalid..

2.3 STORING




Observe external packing instructions .

2.4 HANDLING




Verify unit weight and handling equipment lifting capacity .
Identify critical points during handling (disconnected routes, flights, steps, doors).

Before handling verify that the unit keeps its balance.



- 1 safety rods
- 2 pins



Use protection to avoid the unit damaging .

2.5 PACKING REMOVING

Be careful not to damage the unit.


Recycle and dispose of packing material in conformity with local regulations.

3 - POSITIONING

3.1 PRELIMINARY INFORMATION


Operate in compliance with safety regulations in force.

For detailed information (dimensions, weight, technical characteristics etc.) please refer to the TECHNICAL INFORMATION section.

 Use single protection devices : gloves, glasses ecc.

During positioning consider these elements :


- technical spaces required for the machine and system
- place where the machine will be installed
- electrical connections
- water connections
- air / aeraulic ducts

 Do not consider these elements could decrease performances and operational life of the unit.

3.2 FUNCTIONAL SPACES

Functional spaces are designed to:


- guarantee good unit operation
- carry out maintenance operations
- protect authorized operators and exposed people

 Respect all functional spaces indicated in the TECHNICAL INFORMATION section.

Double all functional spaces if two or more unit are aligned.

3.3 POSITIONING

Units are designed to be installed:


- 
- EXTERNAL
 - in fixed positions

Limit vibration transmission:

- use antivibration devices on unit bearing points
- install flexible joints on the hydraulic connections

Choose the installation place according to the following criteria:

- Customer approval
 - safe accessible position
 - technical spaces requested by the unit
 - spaces for the air intake/exhaust
 - avoid flood-prone places
 - verify unit weight and bearing point capacity
 - verify that all bearing points are aligned and leveled
 - install the unit raised from the ground
 - max. distance allowed by the electrical connections
- Prefer places where the unit doesn't disturb the neighbours.

 Avoid installations next to bedrooms or windows.
Avoid snow accumulations on batteries.

Protect the unit with an appropriate fencing to avoid the access to a not authorized personnel (babies, vandals etc.)
A correct circulation of the air is indispensable to guarantee the good working order of the machine.

Avoid therefore:

- obstacles to the airflow;
- exchange difficulties;
- leaves or other foreign bodies that can obstruct the exchange batteries;
- winds that hinder or favour the airflow;
- heat or pollution sources close to the unit (chimneys, extractors etc);
- stratification (cold air that stagnates at the bottom);
- recirculation (expelled air that is sucked in again);
- positioning below the level of the threshold, close to very high walls, attics or in angles that could give rise to stratification or recirculation phenomena.

Ignoring the previous indications could:

- energy efficiency decrease;
- blocks due to HIGH PRESSURE (in summer) or LOW PRESSURE (in winter).

3.4 FRESH AIR PROBE - OPTIONAL


The external probe allows to automatically change the unit set point according to the external enthalpy (temperature + humidity).

It is then possible to optimize the unit energy efficiency.
POSITIONING

The sensor should not be influenced by factors that can distort the reading (eg direct sunlight, air exhausted from the fan or other sources, contact with the unit structure or other heat sources, accumulations of snow / ice).

Examples to position the external probe :

- A roof
- B under a terrace
- C if at free wall provide a small roofing



4 - WATER CONNECTIONS

4.1 PRELIMINARY INFORMATION

Selection and installation of system components must be carry out by installer.

Following you will find some indications to integrate with what is provided by the local regulations in force and by the good technical laws.

4.2 COMPONENTS

CUT-OFF VALVES

- Installed at inlet and outlet (both on the water technique circuit as well as that of the hot domestic water) allow maintenance operations without having to empty the system .

THERMOMETERS AND MANOMETERS

- Installed at entry and exit of the main elements facilitate inspection and maintenance.

AIR BLEED VALVE

- Installed in all of the highest points of the system allowing the venting of the circuits air..

DRAINAGE TAPS

- Installed in the lowest points of the system to allow bleeding.

EXPANSION TANK

- It keeps a correct system pressure when the water temperature changes. It must be dimensioned as a function of water plant volume and temperature.

WATER FILTER

- If not present on-board the machine, must be installed immediately in the water input of the unit, in a position that is easily accessible for cleaning.

- The filter never should be removed, this operation invalidates the guaranty

SUPPORTS

- The hydraulic pipes weight mustn't burden on the unit connections ..

FLOW SWITCH

- The flow switch must be present as a component of the system

4.3 OPERATION SEQUENCE

1. Carefully wash the system with clean water: fill and drain the system several times.
2. Apply additives to prevent corrosion, fouling, formation of mud and algae.
3. Fill the plant
4. Execute leakage test.
5. Isolate the pipes to avoid heat dispersions and formation of condensate.
6. Leave various point of service free (wells, vent-holes etc).

- Neglecting the washing will lead to several filter cleaning interventions and at worst cases can cause damages to the exchangers and the other parts.

4.4 WATER QUALITY

The water quality is determined by the following factors, avoid therefore:

- Inorganic salts
- pH
- Biological load (seaweeds etc)
- Suspended solids
- Dissolved oxygen

Water with inadequate characteristics can cause:

- pressure drop increase
- energy efficiency decrease
- corrosive symptom increase

4.5 RISK OF FREEZE

If the unit or the relative water connections can be subject to temperatures close to 0°C adopt measures for prevent risk of freeze.

For example:

- Mix water with ethylene glycol
- Safeguard the pipes with heating cables placed under the insulation
- Empty the system in cases of long non-use and check that:
 - there are no closed taps present that could trap water even after emptying
 - there are no low points in which water can stagnate even after emptying; carry out any blowing required .

4.6 ANTI-FREEZE SOLUTION

Consider that the use of anti-freeze solution determines an increase in a pressure drop.

Make sure that the glycol type utilized is inhibited (not corrosive) and compatible with the hydraulic circuit components (pump etc).


Do not use different glicol mixture (i.e. ethylene with propylene)

4.7 WATER CONNECTIONS

- Take away the supplied connection union by acting on the connection joint.
- Weld the union to the installation pipe.
- Perform the connection between the installation pipe and the evaporator, using the joint.


Do not weld the system pipe with the connection joint attached.

The rubber gasket might be irreparably damaged.



4 - WATER CONNECTIONS

4.8 RECOMMENDED CONNECTION



- | | |
|-----------------------------------|----------------------------------|
| 1. Charged system pressure switch | 8. filter |
| 2. vent | 9. filling valve |
| 3. pump | 10. antivibration joints |
| 4. expansion tank | 11. user side exchanger |
| 5. safety valve | 12. Differential pressure switch |
| 6. flow switch | 13. Discharge cock |
| 7. pressure switch/thermometer | 14. inertial storage tank |

WATER CONNECTIONS: see dimensional drawings

STANDARD HYDRAULIC CIRCUIT

- water side safety valve
- impurity trap with filter
- centrifugal pump
- antifreeze heater protection to pumping station
- drain valve


4.9 WATER CIRCUIT EMPTYING

The unit is equipped with outlets for the pump emptying and storage.

Outlets are accessible from the rear side (left side in the figure).

Storage content :

- | | |
|--------------|-----------------------------|
| size 82,122 | 80 litres |
| size 162,302 | 130litres (optional) |



4.10 RECOVERY EXCHANGER

OPTIONAL - The unit can be equipped with exchangers to recover the partial condensation heat.

The customer is responsible for the management of the circulation pump, valves, thermostats, etc

The recovery input water must not be below 25°C, in the event that, wrongful operations and breakages of the unit can occur .

Water connections must be performed carefully as for the evaporator (filter, circuit washing, etc) .

Perform all necessary interventions to avoid the RISK OF FREEZING (tubes insulation, emptying of circuit, addition of glycol, anti-freeze heaters) .

Water temperature can reach high temperatures (up to 100° C), therefore:


- avoid the RISK OF BURNS by adopting the necessary precautions (insulation of tubes, temperature detecting station on water if the sanitary use is foreseen, etc)
- Install safety valves and specifically dimensioned expansion tanks in the hydraulic circuit.

4.11 FREE-COOLING - OPTION

In the compressor department are present drain cocks and air vents for the freecooling coils.



1. Assemble in the rear part of the unit the cocks (low) and the valves (high) .
2. Fill up the water circuit
3. Check the tightness.



5 - ELECTRICAL CONNECTIONS

5.1 PRELIMINARY INFORMATION

The characteristics of the electrical lines must be determined by specialized personnel able to design electrical installations; moreover, the lines must be in conformity with regulations in force.

The protection devices of the unit power line must be able to stop the presumed short circuit current, whose value must be determined in function of system features.

The power cables and the protection cable section must be defined in accordance with the characteristics of the protections adopted. All electrical operations should be performed by trained personnel having the necessary requirements by the regulations in force and being informed about the risks relevant to these activities.

Operate in compliance with safety regulations in force .


5.2 ELECTRICAL DATA



The serial number label reports the unit specific electrical data, included any electrical accessories .

The electrical data indicated in the technical bulletin and in the manual refer to the standard unit, accessories excluded.

Refer to the electrical data report on the serial number label.



F.L.A. full load ampere
Full load current at max admissible conditions

F.L.I. Full load input
Full load power input
(at max. admissible condition)

5.3 CONNECTIONS

1. refer to the unit electrical diagram (the number of the diagram is shown on the serial number label)
2. verify that the network has characteristics conforming to the data shown on the serial number label
3. Before starting work, verify that the sectioning device at the start of the unit power line is open, blocked and equipped with cartel warning
4. Primarily you have to realize the earthing connection
5. Shelter the cables using adequate measure fairleads
6. Before power the unit, make sure that all the protections that were removed during the electrical connection work have been restored.

5.4 SIGNALS / DATA LINES

Do not overpass the maximum power allowed, which varies, according to the type of signal.

Lay the cables far from power cables or cables having a different tension and that are able to emit electromagnetic disturbances.

Do not lay the cable near devices which can generate electromagnetic interferences.


Do not lay the cables parallel to other cables; cable crossings are possible, only if laid at 90°.

Connect the screen to the ground, only if there aren't disturbances

Guarantee the continuity of the screen during the entire extension of the cable.

Respect impendancy, capacity and attenuation indications.

5.5 ELECTRIC LINES INLET



Fix the cables: if vacated may be subject to tearing.




The cable don't have to touch the compressor and the refrigerant piping (they reach high temperatures).

5 - ELECTRICAL CONNECTIONS

5.6 ELECTRICAL PANEL


82 - 122



AP1	Main control module
AP2	Local keyboard
AP3	Expansion module
AP5	RS 485 module
AP11-12	Soft starter

QM1-2	Compressor motor overload cutout
QM3-4	Overload cutout switch pump
KM1-2	Compressor contactor
KM3-4	Pump contactor
QS1	main isolator switch

162 - 302



5 - ELECTRICAL CONNECTIONS

5.8 SET POINT COMPENSATION WITH 4-20 MA SIGNAL (WATER RESET)

It optimizes the energetic efficiency of the unit by automatically changing the set-point according to an external signal of 4-20 ma type. It requests the **expansion plug-in module** option that must be fitted by the client (refer to the kit instructions) and enabled by parameter 140 = 1. This function must be enabled with parameter 18 (=0 not enabled, =1 only summer, = 2 only winter, = 3 summer and winter)

par	description	meaning	value
18	WaterReset	Water Reset enabling 0=No 1=Cool 2=Heat 3=Always	0
19	MaxCWRH	Max. value of the Winter WR correction	10
20	SWRMAXH	Corresponding signal of the winter MAX. correction	4
21	SWRMinH	Corresponding signal of the winter MIN. correction	20
22	MaxCWRC	Summer correction max. value	8
23	SWRMaxC	Corresponding signal of the summer MAX. correction	20
24	SWRMinC	Corresponding signal of the summer MIN. correction	4
140	PlugInEn	Enables PLUG-IN presence . 1=YES / 0=NO	

SET POINT CURVE IN COOLING	

5.9 SET POINT COMPENSATION ON THE TEMPERATURE OR EXTERNAL ENTHALPY


Optimises unit energy efficiency by automatically adjusting the set-point according to enthalpy or the external temperature. Requires the **external humidity probe** or the **external temperature probe**, which are optional for certain types of units and must be installed by the customer and enabled by parameters 152=1 and 156=1.

par	description	meaning	value
9	CompExt	External temp. comp. enabling 0=No 1=Cool 2=Heat 3=Always	0
10	CextMaxC	Ext. Temp. max. summer correction	15
11	CextMinC	Ext. Temp. min. summer correction	30
12	CextMaxH	Ext. Temp. max. winter correction	15
13	CextMinH	Ext. Temp. min. winter correction	0
14	MaxCExtC	Summer correction max. value	8
15	MaxCExtH	Winter correction max. value	10
16	HExtMinC	Ext. enthalpy min. correction	10,5
17	HExtMaxC	Ext. enthalpy max. correction	13,5
152	TextEn	EXT. Air probe presence 1=YES, 0=NO	
156	URProbeExt	Enables external UR% probe. 1=YES, 0=NO	

SET POINT CURVE IN COOLING	


5 - ELECTRICAL CONNECTIONS

5.10 RS485




SHIELD

- It must be connected to a ground without disturbances
- Connected to ground in only one point
- Provide to the shield continuity during all the serial cable extension.




NETWORK CABLE FEATURES

- Couple of conductors twisted and shielded
- Section of conductor $0.22\text{mm}^2 \dots 0.35\text{mm}^2$
- Nominal capacity between conductors $< 50 \text{ pF/m}$
- nominal impedance 120Ω
- Recommended cable BELDEN 3105A




TYPE OF NETWORK

The serial lines must be connected in bus typology, i.e. nodes to more points are not admitted



Make the termination if the unit is the last of the network .
termination yes = dip ON




5 - ELECTRICAL CONNECTIONS




FREE-COOLING OPTION

ELECTRICAL PANEL 82 - 122



ELECTRICAL PANEL 82 - 122 configuration CREFB




5 - ELECTRICAL CONNECTIONS




FREE-COOLING OPTION

ELECTRICAL PANEL 162 - 302



CUSTOMER CONNECTIONS



AP1 Main control module
 XC2 main control module terminal block
 XCA electrical panel terminal block
 SQ1 flow switch
 SA1 remote ON-OFF selector


SA3 remote 2nd setpoint selector
 HL1 shut-down unit signal
 HL2 operating unit signal
 HL3-4 operating compressors unit signal

5 - ELECTRICAL CONNECTIONS



FREE-COOLING OPTION

COLLEGAMENTI CLIENTE



- AP1 main control module
- AP3 remote keypad

RS485

Perform the RS 485 MODULE addressing by S3, S4 S5 ;
allowed and valid addresses from 1 to 127

S3 it sets the address dozens

S4 it sets the address units

S5 it sets the address hundreds
ON = 100, OFF = 0

S1 485 terminator: ON = termination YES


S2 line polarizer:

Inside the 485 net only one card must be polarized, usual-
ly is polarized the master, i.e. the PC ; in this case
S2 = OFF = polarization NO

if more cards are polarized, faults occur

J1 RS 485 serial


J3 TTL serial



5 - ELECTRICAL CONNECTIONS



FREE-COOLING OPTION





- AP10 local keypad
- AP5 RS485 module

pag 16 : TYPE OF NETWORK
NETWORK CABLE FEATURES




FREE-COOLING OPTION

SET POINT CORRECTION ON OUTSIDE TEMPERATURE and EXT. HUMIDITY



Summer



With low outside temperatures the refrigerant requirement is reduced.
The internal comfort can be also obtained by a set-point higher than standard.
The correction is summed to the set-point (it increases at the outside temp. decreasing)



PARAMETERS TO BE PERSONALIZED


- 4 Enables compensation (0=No 1=Cool 2=Heat 3=Always)
- 104 Outside temp.: max. Summer correction
- 105 Outside temp.: min. Summer correction
- 108 Summer correction max. value

WATER RESET



SUMMER

If the refrigerant requirement is low, the setpoint is raised : the WR signal is high or maximum.
The correction is summed to the set-point (it increases at the outside temp. decreasing)



PARAMETERS TO BE PERSONALIZED

- 5 Enables Water Reset (0=No 1=Cool 2=Heat 3=Always)
- 130 Summer correction max. value
- 131 Summer correction MAX signal
- 132 Summer correction MIN signal

6 - START-UP

PRELIMINARY CHECKS



To check **before** starting-up the unit .

For details refer to the different manual sections.

<input checked="" type="checkbox"/> Preliminary checks - Unit OFF power supply
<input type="checkbox"/> Access in safety
<input type="checkbox"/> Functional clearances
<input type="checkbox"/> Air flow : free return and supply (no bypass, no stratification)
<input type="checkbox"/> Structure integrity
<input type="checkbox"/> Fans run freely
<input type="checkbox"/> Unit on vibration isolators
<input type="checkbox"/> Unit input water filter + shut-off valves for cleaning
<input type="checkbox"/> Vibration isolators on water connections
<input type="checkbox"/> Expansion tank (indicative volume = 5% system content)
<input type="checkbox"/> Cleaned system
<input type="checkbox"/> Loaded system + possible glicole solution + corrosion inhibitor
<input type="checkbox"/> Under pressure system
<input type="checkbox"/> Vented system
<input type="checkbox"/> Refrigerant circuit visual check
<input type="checkbox"/> Earthing connection
<input type="checkbox"/> Power supply features
<input type="checkbox"/> Electrical connections provided by the customer
<input type="checkbox"/> Outside air temperature probe

6 - START-UP

START-UP SEQUENCE



Operations to perform to start-up the unit.

For details refer to the different manual sections.

<input checked="" type="checkbox"/> Start-up sequence - Unit ON power supply
<input type="checkbox"/> Compressor carter resistances operating at least since 8 hours
<input type="checkbox"/> Off-load voltage measure
<input type="checkbox"/> Phase sequence check
<input type="checkbox"/> Pump manual start-up and flow check
<input type="checkbox"/> Unit ON
<input type="checkbox"/> Load voltage measure and absorptions
<input type="checkbox"/> Liquid light check (no bubbles)
<input type="checkbox"/> Check of all fan operating
<input type="checkbox"/> Measure of return and supply water temperature
<input type="checkbox"/> Super-heating and sub-cooling measure
<input type="checkbox"/> Check no anomalous vibrations are present
<input type="checkbox"/> Set-point personalization
<input type="checkbox"/> Climatic curve personalization
<input type="checkbox"/> Complete and available unit documentation

6 - START-UP

6.1 PRELIMINARY INFORMATION

The indicated operations should be done by qualified technician with specific training on the product.

Upon request, the service centres performing the start-up; the electrical, water connections and the other system works are by the installer.

Agree upon in advance the star-up data with the service centre.

6.2 PRELIMINARY CHECKS

Before checking, please verify the following :

- the unit should be installed properly and in conformity with this manual.
- the electrical power supply line should be sectioned at the beginning.
- The line sectionalizing device is open, locked and equipped with the suitable warning
- make sure no tension is present

6.3 REFRIGERANT CIRCUIT

1. Check carefully the refrigerating circuit: the presence of oil stains can mean leakage caused by transportation, movements or other).
2. Verify that the refrigerating circuit is in pressure: Using the unit manometers , if present, or service manometers.
3. Make sure that all the service outlets are closed with proper caps; if caps are not present a leak of refrigerant can be possible.

6.4 HYDRAULIC CIRCUIT

1. Before realizing the unit connection make sure that the hydraulic system has been cleaned up and the clearing water has been drained
2. Check that the water circuit has been filled and pressurized
3. Check that the shut-off valves in the circuit are in the "OPEN" position.
4. Check that there isn't air in the circuit, if required, evacuate it using the air bleed valve placed in the system high points.
5. When using antifreeze solutions, make sure the glycol percentage is suitable for the type of use envisaged.

Weight of glycol (%)	10	20	30	40
Freezing temperature (°C)	-4	-9	-15	-23
Safety temperature (°C)	-1	-4	-10	-19

6.5 ELECTRICAL CIRCUIT

Verify that the unit is connected to the ground plant

Check the conductors tightening: the vibrations caused by handling and transport might cause loosing

Feed the unit by closing the sectioning device, but leave it on OFF.

Check the tension and line frequency values which must be within the limits :

400/3/50 +/- 10%

Control the unbalancing of the phases:

it must be lower than 2%

Example:

1) $\frac{388 + 379 + 377}{3} = 381$

2) $388 \text{ (max)} - 381 = 7$

3) $\frac{7}{381} \times 100 = 1,83 \text{ OK}$



The working out of the limits can cause irreversible damages and voids the warranty.

6.6 COMPRESSOR CRANKCASE RESISTANCES

Connect the oil resistances on the compressor crankcase at least 8 hours before the compressor is to be starter :

- at the first unit start-up
 - after each prolonged period of inactivity
1. Supply the resistances switching off the unit isolator switch.
 2. To make sure that the resistances are working, check the power input .
 3. At start-up the compressor crank-case temperature on the lower side must be higher at least of 10°C than the outside temperature.



Do not start the compressor with the crankcase oil below operating temperature.

6.6 TENSIONS

Check that the air and water temperatures are included in the working limits

For information on the control system, refer to the paragraph CONTROL.

Start the unit

With unit of full load, namely in stable conditions and close to those of work, check :

- Power supply tension
- Total absorption of the unit
- Absorption of the single electric loads

6.7 REMOTE CONSENT

- Check that the remote commands (ON-OFF, etc.) are connected and if necessary enabled with the relevant parameters as described in ELECTRICAL CONNECTIONS section
- Check that probes or optional components are connect and enable with the relative parameters(ELECTRICAL CONNECTION section)

6.8 STARTING REPORT

Realize the operating objective conditions is useful for check the unit over time.

With unit of full load, namely in stable conditions and close to those of work, take the following data:

- Tension and general absorptions with unit at full load
- Absorption of varied electrical loads (compressors, fans, pumps etc)
- Temperatures and capacities of different liquid (water, air) in the inlet and outlet of the unit
- Temperatures and pressures on the refrigerant circuit characteristic points (compressor discharge, liquid, intake)

The remarks should be preserved and available during maintenance .

6.9 CE 97/23 PED DIRECTIVE

97/23 CE PED DIRECTIVE gives instructions for installers, users and maintenance technicians as well.


Refer to local actuation norms; briefly and as an example, see the following

- Compulsory verification of the first installation :
only for units assembled on the installer's building site
(for ex. Condensing circuit + direct expansion unit)
- Certification of setting in service :
for all the units
- Periodical verifications:
to be executed with the frequency indicated by the manufacturer (see the maintenance section)

7 - CONTROL

7.1 MULTI-FUNCTION KEYPAD

The HEATING mode functions are active only on HEAT PUMP unit version .
 In ONLY COOL units, the relative parameters are VISIBLE but NOT ACTIVE , for example the winter setpoint.



OPERING MODES

ON – OFF	Unit can be switched on and off by: <ul style="list-style-type: none"> • remote or service keypad • remote switch (see ELECTRICAL CONNECTIONS paragraph) • Supervisor
COOLING	The compressor is activated with outlet temperature higher than set point
ECO	A secondary set-point can be used, with respect to the comfort setting. In heating the ECO-set is lower than the standard set , in cooling the ECO-set is higher than the standard set.
MAINTENANCE	the plant can be kept within the operating limits even when the unit is OFF or on STANDBY

THERMOREGULATION

The thermoregulation is based on the OUTLET temperature.

The unit is dimensioned for a determined TOTAL HEAD between input and output water temperature.

Usually the project step is 5°C; if the value is different, it is necessary reset parameters 37 and 38 (accessible to the service centre).

In function of the total head, the installation determines the head quote that every resource (compressor, heating elements) is able to provide: the STEP HEAD.


The control logic insert gradually the resources when the outlet temperature is higher than the set point + the head step.

The resources are activated one at a time and only at the SCAN TIME expiring.

The scan time is not fixed but it changes in function of the margin between the water outlet temperature and the Set point value. Higher is the margin value (both in positive and in negative) shorter will be the space among the scan points.

The scan time value is visualized at status 4; when the status 3 has reached the status 4 value, the compressor operating request is activated.

What above described, refer to the COOLING operating.




7 - CONTROL

SET-POINT COMPENSATIONS

The compensations are evolved functions to protect the compressors and to adapt, as far as possible, the unit operating to the installation and use characteristics.

The compensations prolong the compressor operating time and limit the start number; to do this they delay the compressor insertion point adding an offset.



- The compensation on the DURATION is useful when the installation water content is limited.
- The compensation on the CHARGE is useful if the variable charge is present.

For the enabling and the configuration is necessary the parameter modification with reserved access to the service centres.

In industrial applications where is requested a temperature check is possible to disable the COMPENSATIONS.

SET-POINT CORRECTIONS

The correction aim is to optimize the unit energetic efficiency.

To do this the corrections modify the set point in a dynamic way in function of determined variables: for example in summer operating with low external temperatures, so with a reduced charge, is possible to obtain the internal comfort also with set point higher than standard, obtaining a higher energetic efficiency.



The static set point can so be modified in a dynamic way by two CORRECTIONS based on as many unit external factors:

- correction based on the ext. temp. / enthalpy
- correction based on the Water reset (4-20 mA signal provided by the Client)

The correct set point, to whom have been summed or removed the corrections, is named ACTUAL set-point and it is visible at status n°1.

The STATA menu visualizes the compensation value on the ext. temperature (status 5) and WR (status 6)

For further details see the ELECTRICAL CONNECTIONS section

7 - CONTROL

CIRCULATION PUMP

The pump is always activated with the units ON.

The delivery capacity is variable to soften the thermal shock to the compressors when the plant temperature is close to the threshold limits.

Delivery capacity depends on the intake temperature:

- SUMMER: high water temperature reduces delivery

VENTILATION

Fans are controlled with a variable speed:

- in SUMMER, the speed increases according to the increase of external air temperature

SET POINT

SET-POINT CALCULATION:

- desired medium outlet water temperature = 7°C
- Project temperature differential = 5°C (that is inlet water = 12°C)
- $\frac{1}{4}$ of the project temperature differential = $5 / 4 = 1.25^\circ\text{C}$
- set-point to be set = $7 - 1.25 = 5.7^\circ\text{C}$

SECONDARY SET POINT – ECO

A secondary set point can be used with different levels to the “normal” set point.

It is normally set to give lower energy consumption with respect to the comfort setting:

- The SECONDARY SUMMER set point is higher than the SUMMER setting.

It can be set according to individual requirements.

- Secondary summer set-point parameter 29

It can be activated from the keyboard, supervisor unit or the remote control.


To change it using the remote control refer to the ELECTRIC WIRING paragraph.

7 - CONTROL

MAINTENANCE

This way, the plant can be kept within the operating limits even when the unit is OFF or on STANDBY, for example during the weekend or the nighttime.

Periodically the system activates the circulation pump, measures the water temperature and activates the compressor, if required, to take the water temperature to the set-point level.



- Summer maintenance set-point par 42

This function is activated by parameters 44 (activate summer maintenance level) and 45 (activate winter maintenance level). With unit in maintenance mode, the display visualizes **STB**.


FUNCTIONING WITH ETHYLENE GLYCOL

The units foreseen to function with glycoled water come out from the premise with standard parameters.

After having added glycol ethylene to water, the technician will properly set the plant.

Parameter to modify:	32	Summer set point
	77	Antifreeze heater set
	80	Antifreeze alarm
	84	Antifreeze pre-alarm threshold

KEYPAD





7 - CONTROL


ACCESSIBLE PARAMETERS FROM REMOTE OR SERVICE KEYBOARD


num. Par.	description	Value	UM
29	Summer secondary Set Point	10	°C
32	Summer Set Point	5.7	°C
42	Summer Set Point Maintenance	20	°C
44	Enables Summer Maintenance	0	num
77	Antifreeze heater set point	4	°C
80	Antifreeze alarm	4	°C
84	Limit of deactivation before reaching the antifreeze steps	4.5	°C
163	Configures remote inputs: 1 = H/C by keypad or supervisor		
192	Keypad address		


PARAMETER MODIFICATION

1  Push SET button

2  Select the parameter

3  Modify the value

4  Select another parameter

5  SET to esc


VISIBLE STATUS FROM REMOTE KEYBOARD OR SERVICE KEYBOARD

Visible status from remote keyboard or service keyboard		
INDEX	DESCRIPTION	VALUE
1	Current Set Point	°C
2	Temperature drop in degrees centigrade given by the compressor including compensations, if any	°C
3	Resource activation timer When this value reaches the value fixed at the 4 status, the thermal regulator will compare the input temperature with the set point and will activate the resources, if necessary	Seconds
4	Dynamic TimeScan relating to source activation	Seconds
5	Value in degrees of the external air compensation	°C
6	Value in degrees of the water reset signal compensation	°C
7	Value in degrees of the charge compensation	°C
9	Inlet temperature	°C
10	Outlet temperature 1	°C
11	Outlet temperature 2	°C
12	Coil temperature 1	°C
13	Condensing pressure 1	Bar
14	Fan/Coil percentage 1	0-100%
15	Coil temperature 2	°C
16	Condensing pressure 2	Bar
17	Condensing pressure 2	Bar
18	Water Reset signal value	4-20 mA

7 - CONTROL

INDEX	DESCRIPTION	VALUE
19	Outdoor temperature	°C
20	Outdoor Humidity	0-100%
21	Machine Clock - fed unit hours	Num
22	Working hours C1	Num
23	Pickups C1	Num
24	Working hours C2	Num
25	Pickups C2	Num
30	Keypad software	AS – t
31	Year of certification of the keyboard SW	2007
32	Month of certification of the keyboard SW	03
33	Day of certification of the keyboard SW	04
34	Base Software	AS – b
35	Year of certification of the keyboard SW	2007
36	Month of certification of the keyboard SW	1
37	Day of certification of the keyboard SW	11

STATUS DISPLAY



ALARMS

BEFORE RESETTING THE ALARM, IDENTIFY AND ELIMINATE THE CAUSE OF ITS ACTIVATION.
 REPEATED RESETS CAN CAUSE IRREVERSIBLE DAMAGES.

The **ALARMS** show a potentially dangerous situation for machine safety.

Before resetting the alarm, discover and remove the cause: repeated resetting could cause irreversible damage. To avoid this, the unit can only be reset **MANUALLY** from the keyboard (only when the cause for the alarm has been removed).

PRE-ALARMS and SIGNALS warn of a risky situation. These could be acceptable only if they happen occasionally or in transitory situations (for example when the plant is being started up).

They are reset **AUTOMATICALLY**, as soon as the cause has been removed, without any input from the keyboard.

The pre-alarms are signalled by the fixed C code (not flashing) and on the right the control temperature.

The **FAULTS** warn of problems with the probes and transducers, and are reset **AUTOMATICALLY** to allow the unit to continue running, perhaps with fewer functions.






In case of doubt, always contact an authorised service centre.

The presence of an alarm is signalled by the **ALARM CODE** flashing and the time at which the alarm/alarms occurred.

The cumulative block relay activates simultaneously to the alarm code visualization.

Certain alarms, in particular **PRE-ALARMS**, do not activate the relays.

ALARM VISUALIZATION

- 1**  flashing
Alarm code
Alarm unit hours
- 2**  opened alarm log
short pressure
ALARM
- 3**  The most recent alarm is visualized
Use the arrow keys to visualize other alarms
- 4**  To esc
Short pressure
ALARM
- 5**  To RESET
LONG pressure
ALARM

According to the unit configuration and to the current options, some status can not be used.

INDEX	ALARM	RESET	
E	1	Faulty or disconnected water inlet probe	Auto.
E	2	Faulty or disconnected water outlet probe 1	Auto.
E	3	Faulty or disconnected water outlet probe 2	Auto.
E	4	Faulty or disconnected coil probe 1	Auto.
E	5	Faulty or disconnected coil probe 2	Auto.
E	6	Faulty or disconnected external probe	Auto.
E	7	Faulty or disconnected pressure transducer 1	Auto.
E	8	Faulty or disconnected pressure transducer 2	Auto.
C	9	Water Reset inlet in short circuit or out of range	Auto.
E	10	Faulty or disconnected external RH% probe	Auto.
E	11	High pressure 1	MANUAL
E	12	Low pressure 1	Auto.
E	13	Condensing fan and/or compressor thermal 1 switch	MANUAL
E	14	High pressure 2	MANUAL
E	15	Low pressure 2	Auto.
E	16	Condensing fan and/or compressor thermal 2 switch	MANUAL
E	17	Pump flow	Auto.
E	18	Pressure switch of the charged system or pump thermal system (if present on board)	MANUAL
E	19	Phase monitor	Auto.
E	20	Antifreeze alarm	MANUAL
C	21	Antifreeze PREAlarm	Auto.
C	22	High pressure PreAlarm 1	Auto.
C	23	High pressure PreAlarm 2	Auto.
C	24	Pump change	Auto.
E	25	C1 flow alarm	Auto.
E	26	C2 flow alarm	Auto.
C	27	C1 low temperarue alarm	Auto.
C	28	C2 low temperarue alarm	Auto.
E	33	Condenser frost alarm	MANUAL
E	34	Evaporator input temp. alarm	Auto.
E	35	Incongruent DeltaT alarm	MANUAL
C/E	36	BP1 Low pressure pre-alarm C1	Auto.
C/E	37	BP1 Low pressure pre-alarm C2	Auto.

S = anomalous situation signalisation that doesn't compromise the unit functionality

E = ALARM, situation that compromises the unit functionality

7 - CONTROL




FREE-COOLING OPTION

The HEATING mode functions are active only on HEAT PUMP unit version .

In ONLY COOL units, the relative parameters are VISIBLE but NOT ACTIVE , for example the winter setpoint.

BUTTON FUNCTION

The display is illuminated only when the keypad is on the support and is operating. The display is automatically extinguished if it is not used for a short period .



SYMBOL VISUALIZATION

Icon	Meaning	Notes
	Flat battery	
	Summer operating	symbols in alternative between them
	Winter operating	
	Alarm in progress	
	Compressors not timed	symbols in alternative between them
	Timed compressor 1	
	Timed compressor 2	
	All (or only one) timed compressors	
	Boiler	
	Active pump	



FREE-COOLING OPTION

System controls	Off Comfort Economic Automatic Only DHW
System modalities	Cooling Heating
Stata visualization	Base info (installer use) Keypad info (installer use) Unit stata (installer use) Stata I/O (installer use)
Alarms	Active alarms Alarm log Alarm reset Log reset
Configuration	Keypad Unit System variables
Scheduling	Weekly Programs Name modification
Date and hour	Day Month Year Hour
Password	Password entering



FREE-COOLING OPTION

CONFIGURATION

1

Press.

2

Select CONFIGURATION and confirm.

3

Select the parameter to modify and confirm.

4

Enter the value and confirm.

Press Home to go back to the normal visualization.

USER PARAMETER LIST

id	Descrizione	Descrizione estesa
10	MantCoolEn	Enable summer maintenance 1=yes, 0=no
11	MantHeatEn	Enable winter maintenance 1=yes, 0=no
21	RemMode	Set remotes inputs Set remote inputs 0=H/C or H/DHW only or C/Solo sanitari/DHW only from ID, 1=digital input no effect
28	EnAntiRug	Enable anti-dew compensation 1=Yes/0=No
43	SetCool	Summer Set Point
44	SetHeat	Winter Set Point
45	SecondSetC	Secondary summer Set Point
46	SecondSetH	Secondary winter Set Point
220	SetMantCool	Summer maintenance Set Point
221	SetMantHeat	Winter maintenance Set Point
364	SetH2OSanitaria	DHW Set Point
451	SetHeater	Antifreeze resistance Set Point
454	AlFreeze	Antifreeze alarm
458	PreAF	Deactivation threshold of Pre antifreeze steps
460	SetfreezeExt	Source water temperature threshold for Coil freeze Alarm activation
461	SetHeaterExt	Source water temperature threshold for antifreeze resistance activation
539	IstTamb	Ambient temperature hysteresis



FREE-COOLING OPTION

ALARMS

- 1**

Fri. 17/10/08		18:02	
Status	ECO		
Setpoint	19.0	100 %	
T In	17.0		
T Out	26.0		

Press
- 2**

Main Menu	
System controls	
System modalities	
ALARMS	
Configurations	

Select ALARMS and confirm.
- 3**

Alarm Menu	
Active alarms	
Alarm log	
Alarm reset	
Log reset	

Select and confirm:

 - Active alarms;
 - Alarm log;
 - Active alarm reset;
 - Log reset of all alarms.
- 4**

Active alarms	
XXXXX	
Alarm description	
Date	XXXX
Hour	XXXX

Alarm visualization.

If no alarms are present.

Zero alarms
OK

Press Home to go back to the normal visualization.

IMMEDIATE ACCESS (only if alarms are present)

- 1**

Fri. 17/10/08		18:02	
Status	ECO		
Setpoint	19.0	100 %	
T In	17.0		
T Out	26.0		

Press.
- 2**

Alarm Menu	
Active alarms	
Alarm log	
Alarm reset	
Log reset	

Select ACTIVE ALARMS and confirm.
- 3**

Active alarms	
E03	
Out. Temp. probe	
Date	08/08/09
Hour	12:45

Alarm visualization.

Press Home to go back to the normal visualization.

ALARMS RESET

- 1**

Fri. 17/10/08		18:02	
Status	ECO		
Setpoint	19.0	100 %	
T In	17.0		
T Out	26.0		

Press.

Before resetting an alarm identify and remove the cause that generate it
- 2**

Main Menu	
System controls	
System modalities	
ALARMS	
Configurations	

Select ALARMS.
- 3**

Alarm Menu	
Active alarms	
Alarm log	
Alarm reset	
Log reset	

Select ALARM RESET and confirm.
- 4**

Alarm Menu	
Active alarms	
Do you confirm reset?	
OK	
Log reset	

Confirm to reset.

Press Home to go back to the normal visualization.


Repeated reset can cause irreversible damages as malfunctioning of the system itself.

In case of doubt please contact an Assistance Centre.





FREE-COOLING OPTION



LOG RESET (for manufacturer use)



Press.




Select ALARMS.




Select LOG RESET and confirm.

This function deletes all the saved alarms.



Enter the password and confirm.

If no alarms are present.



Press Home to go back to the normal visualization.



FREE-COOLING OPTION

ALARM LIST

e	00	Base keypad Timeout	A	N
E	01	Utility input temperature probe	A	S
E	02	Utility supply temperature probe	A	S
E	03	Outdoor temperature probe	A	S
E	04	Temp. probe of source output/coil	A	S
E	05	Return temperature probe source side	A	S
E	06	Temp. probe in storage	A	S
E	07	Temp. probe of utility AUX heater Sonda temp. riscaldatore AUX utilizzo	A	S
E	08	Pressure 1 probe (HP)	A	S
E	09	Pressure 1 probe (LP_TE)	A	S
E	10	Externe RH% probe	A	S
E	11	Water Reset Input	A	S
E	12	Demand Limit Input	A	S
E	13	Phase monitor	A	S
e	14	Capacity reading Timeout	A	S
F	01	High pressure (HP)	A/M	S
F	02	Low pressure (LP)	A/M	S
F	03	Compressor 1 overload (or softstater)	M	S
F	04	Compressor 2 overload (or softstater)	M	S
f	05	Prealarm HP1	A	S
f	06	Prealarm LP1	A	S
F	07	Fan overload	M	S
f/F	08	Prealarm HP2	A/M	S
f/F	09	Prealarm LP2	A/M	S
f/F	10	Max pressure ratio	A/M	S
f/F	11	Defrosting forcing for low pressure	A/M	N/S
f/F	12	Defrosting alarm	A/M	S

A = AUTOMATIC reset

M = MANUAL reset

S = it is memorie in the alarm log

N = it is NOT memorie in the alarm log



FREE-COOLING OPTION

ALARM LIST

I	01	Utility pump flow	A/M	S
I	02	Source pump flow	A	S
I	03	Pump 1 overload (utility side)	M	S
I	04	Pump 2 overload (utility side)	M	S
I	05	Frost alarm (utility)	M	S
I	06	Frost alarm source side	M	S
I	07	AUX heater antifreeze	M	S
I	08	Water charge system (utility)	M	S
I	09	Incongruent T Delta	M	S
I	10	Thermal alarm on all pumps (utility side)	M	
i	11	Antifreeze prealarm (utility)	A	S
i	12	Pump change (utility)	A	N
i	13	User input water temperature out of limit of the current operating mode	A	S
i	14	Dom. hot water incongruent thermostat	A	N
I	15	Ambient antifreeze alarm	A	S
I	16	Pump heat alarm source side	M	S

A = AUTOMATIC reset

M = MANUAL reset

S = it is memorie in the alarm log

N = it is NOT memorie in the alarm log

7 - CONTROL



FREE-COOLING OPTION

LIST OF STATA

Num. status	DESCRIPTION	UM
1	Current Set point	°C
2	Current step difference (with compensations)	°C
3	Resource insertion timer	Seconds
4	Dynamic TimeScan of the resource insertion	Seconds
5	Outside T compensation	°C
6	Ambient T compensation	°C
7	WR compensation	°C
8	Charge compensation	°C
9	Duty Cycle compensation	°C
10	Compensation on duration	°C
11	Water input temperature	°C
12	Water output temperature	°C
13	Aux. heater output temperature	°C
14	Fresh air temperature	°C
15	Condensing coil temperature	°C
16	Storage temperature	°C
17	Utility 1 pump	
18	Utility 2 pump	
19	Ventilation	
20	Condensing pressure	Bar
21	Evaporating pressure	Bar
22	Aux. heater	
23	Aux. heater (0-10V)	%
24	Boiler control	
25	Relative humidity	%
26	Source valve or Free cooling	
27	Compressor at variable speed (0-10V)	%
28	Compressor 1 operating hours	
29	Compressor 1 starts	
30	Compressor 2 operating hours	
31	Compressor 2 starts	
32	Defrosting delay (SeTypeDFR = 0)	
33	Defrosting count (SeTypeDFR = 0)	
34	Ambient dew temperature	
35	Mininet: X=node disconnected O=Node connected	
36	Electric power absorbed	

8 - MAINTENANCE

8.1 GENERAL

Maintenance must be done by authorized centres or by qualified personnel

The maintenance enables:

- maintain the unit efficiency
- Reduce the deterioration speed to whom every equipment is subject over time
- Assemble information and data to understand the state of the unit efficiency and avoid possible damages

8.2 INSPECTIONS FREQUENCY

The inspections should be carried out at least every six months

The frequency, however, depends on the use .



In the event of frequent use it is recommended to plan inspections at close intervals :

- frequent use (continuous or very intermittent use, near the operating limits, etc)
- critical use (service necessary) .

8.3 MACHINE BOOKLET

It's advisable to create a machine booklet to take notes of the unit interventions.

In this way will be easier marker the various interventions and will be e facilitate any troubleshooting.

Report on the booklet :

- data
- type of intervention effected
- intervention description
- Carried out measures etc ..

8.4 PUT A REST

If a long period of inactivity is foreseen

- Turn of the power in order to avoid electrical risks or damages by lightning strike
- avoid the risk of frosts (empty or add glycol in the plant sections subjected to temperatures below zero , power antifreeze resistances if are present)

It's recommended that the starter after the period of detention is made by a qualified technician, especially after seasonal stops or seasonal switch.

When restarting, refer to the START-UP section .



Schedule technical assistance in advance to avoid hitches and be able to use the installation when necessary.

8.5 WATER FILTER

Verify that there are no impurities which hinder the smooth passage of water.

8.6 CIRCULATION PUMPS

Verify :

- no leaks
- Bearing status (anomalies are highlighted by abnormal noise and vibration)
- The closing of the terminals cover and the correct positioning of the cable glands.

8.7 WATER EXCHANGER

It is very important for the exchanger to be able to provide the maximum thermal exchange. Therefore, it is essential for the inner surfaces to be clean of dirt and incrustations.

Periodically check the difference between the temperature of the supply water and the condensation temperature. If the difference is greater than 8 °C – 10 ° C it is advisable to clean the exchanger.

The clearing must be effected :

- With circulation opposite to the usual one
- With a speed at least 1,5 times higher than the nominal one
- With an appropriate product moderately acid (95% water + 5% phosphoric acid
- After the cleaning rince with water to inhibe the detergent rests.

8.8 ELECTRIC FANS

Check :

- the fans and the relative protection gridsare well fixed
- The fan bearings (evident by noise and anomalous vibrations)
- the terminal protection covers are closed and the cable holders are properly positioned

8.9 AIR COIL





Contact with the exchanger fins can cause cuts. Wear protective gloves to perform the above described operations. It is extremely important that the battery gives the maximum thermal exchange; therefore, its surface must be cleaned from dust and deposits. Remove all impurities from the surface.

It is extremely important that the battery gives the maximum thermal exchange; therefore, its surface must be cleaned from dust and deposits. Remove all impurities from the surface. Using an air pressure gun, clean the aluminum surface of the battery. Be careful to direct the air in the opposite direction of the fan air movement.



Hold the gun parallel to the fins to avoid damages. As an alternative, an aspirator can be used to suck impurities from the air input side.

Verify that the aluminum fins are not bent or damaged. In the event of damages, contact the authorized assistance center and get the battery "ironed out" in order to restore the initial condition for an optimal air flow



8 - MAINTENANCE

CONTROL CHECK LIST

Controls effected onBy Of the Company.....

√		1	6	12
<input type="checkbox"/>	Presence of corrosions			●
<input type="checkbox"/>	Panel fixing			●
<input type="checkbox"/>	Fan fixing		●	
<input type="checkbox"/>	Coil cleaning		●	
<input type="checkbox"/>	Water filter cleaning		●	
<input type="checkbox"/>	Check the exchanger efficiency			●
<input type="checkbox"/>	Circulating pumps		●	
<input type="checkbox"/>	Check of the fixing and the insulation of the power lead		●	
<input type="checkbox"/>	Check of the earthing cable		●	
<input type="checkbox"/>	Electric panel cleaning			●
<input type="checkbox"/>	Capacity contactor status		●	
<input type="checkbox"/>	Terminals closing, cable insulation integrity			●
<input type="checkbox"/>	Voltage and phase unbalancing (no load and on-load)		●	
<input type="checkbox"/>	Absorptions of the single electrical loads		●	
<input type="checkbox"/>	Test of the compressor carter resistances		●	
<input type="checkbox"/>	Leak control *			●
<input type="checkbox"/>	Survey of the refrigerant circuit operating parameters		●	
<input type="checkbox"/>	Protective device test : safety valves, pressure switches, thermostats, flow switches etc		●	
<input type="checkbox"/>	Control system test: setpoint, climatic compensations, capacity stepping, water / air flow-rate variations etc		●	
<input type="checkbox"/>	Control device test : alarm signalling, thermometers, probes, pressure gauges etc		●	

Notes / interventions recommended to the owner

* European regulation 303/2008


Refer to the local actuation regulations; in short and just as an indication the regulation order as follow.

Companies and technicians that effect interventions of installation, maintenance/repairs, leak control and recovery must be CERTIFIED as expected by the local regulations.

The leak control must be effected with annual renewal.

9 - TECHNICAL INFORMATION

DIMENSIONALES AND WEIGHT DISTRIBUTION WSA-N-XEE 82-102-122




SIZES		STANDARD			FREE-COOLING	
		82	102	122	82	102
M	mm	599	598	587	613	611
N	mm	843	842	838	784	786
O	mm	289	289	283	260	260
P	mm	337	336	333	337	336
Length	mm	1771	1771	1771	1771	1771
Depth	mm	680	680	680	680	680
Height	mm	1287	1287	1287	1287	1287
W1	kg	83	85	90	89	90
W2	kg	54	55	57	66	66
W3	kg	98	100	107	118	119
W4	kg	63	64	68	86	87
Operating weight	kg	298	303	323	359	362
Shipping weight	kg	304	309	328	348	351

- (1) COMPRESSOR COMPARTMENT
- (2) ELECTRICAL PANEL
- (3) KEYBOARD CONTROL UNIT
- (4) POWER INPUT
- (5) FUNCTIONAL SPACE
- (6) AIR SUPPLY
- (7) WATER INLET 1 1/4" VICTAULIC
- (8) WATER OUTLET 1 1/4" VICTAULIC
- (9) DESUPERHEATER WATER INLET 1" 1/4 VICTAULIC (OPTIONAL)
- (10) DESUPERHEATER WATER OUTLET 1" 1/4 VICTAULIC (OPTIONAL)
- (11) MAIN ISOLATOR SWITCH
- (12) VIBRATION MOUNTS POSITION
- (13) LIFTING HOLES POSITION

OPTIONAL ACCESSORIES MAY RESULT IN A SUBSTANTIAL VARIATION OF THE WEIGHT SHOW IN TABLE

9 - TECHNICAL INFORMATION

DIMENSIONALS AND WEIGHT DISTRIBUTION WSA-N-XEE 162-182-222




SIZE		STANDARD			FREE-COOLING		
		162	182	222	122	162	182
M	mm	678	675	700	759	706	705
N	mm	1183	1180	1139	1030	1096	1099
O	mm	466	460	442	422	422	423
P	mm	566	566	571	549	559	560
Length	mm	2012	2012	2012	2012	2012	2012
Depth	mm	1100	1100	1100	1100	1100	1100
Height	mm	1599	1599	1599	1599	1599	1599
W1	kg	140	143	141	132	154	156
W2	kg	65	66	72	87	84	85
W3	kg	172	178	184	174	206	209
W4	kg	79	82	94	114	112	113
Operating weight	kg	456	469	490	507	556	563
Shipping weight	kg	464	476	497	493	542	548

- (1) COMPRESSOR COMPARTMENT
- (2) ELECTRICAL PANEL
- (3) KEYBOARD CONTROL UNIT
- (4) POWER INPUT
- (5) FUNCTIONAL SPACE
- (6) AIR SUPPLY
- (7) WATER INLET 2" VICTAULIC
- (8) WATER OUTLET 2" VICTAULIC
- (9) DESUPERHEATER WATER INLET 1" 1/4 VICTAULIC (OPTIONAL)
- (10) DESUPERHEATER WATER OUTLET 1" 1/4 VICTAULIC (OPTIONAL)
- (11) MAIN ISOLATOR SWITCH
- (12) VIBRATION MOUNTS POSITION
- (13) LIFTING HOLES POSITION

OPTIONAL ACCESSORIES MAY RESULT IN A SUBSTANTIAL VARIATION OF THE WEIGHT SHOW IN TABLE

9 - TECHNICAL INFORMATION

DIMENSIONALS AND WEIGHT DISTRIBUTION WSAN-XEE 262-302



SIZE		STANDARD		FREE-COOLING		
		262	302	222	262	302
M	mm	865	862	654	671	677
N	mm	1143	1138	1062	1036	1038
O	mm	429	426	410	405	408
P	mm	596	593	564	572	571
Length	mm	2406	2406	2406	2406	2406
Depth	mm	1100	1100	1100	1100	1100
Height	mm	1593	1593	1593	1593	1593
W1	kg	134	138	154	150	153
W2	kg	93	95	119	126	127
W3	kg	189	194	215	215	217
W4	kg	131	138	166	180	181
Operating weight	kg	547	561	654	671	677
Shipping weight	kg	556	569	633	649	654

- (1) COMPRESSOR COMPARTMENT
- (2) ELECTRICAL PANEL
- (3) KEYBOARD CONTROL UNIT
- (4) POWER INPUT
- (5) FUNCTIONAL SPACE
- (6) AIR SUPPLY
- (7) WATER INLET 2" VICTAULIC
- (8) WATER OUTLET 2" VICTAULIC
- (9) DESUPERHEATER WATER INLET 1" 1/4 VICTAULIC (OPTIONAL)
- (10) DESUPERHEATER WATER OUTLET 1" 1/4 VICTAULIC (OPTIONAL)
- (11) MAIN ISOLATOR SWITCH
- (12) VIBRATION MOUNTS POSITION
- (13) LIFTING HOLES POSITION

OPTIONAL ACCESSORIES MAY RESULT IN A SUBSTANTIAL VARIATION OF THE WEIGHT SHOW IN TABLE

9 - TECHNICAL INFORMATION

GENERAL TECHNICAL SPECIFICATIONS

Size		82	102	122	162	182	222	262	302	
COOLING										
Cooling capacity	1	kW	24,3	28,2	33,7	40	45,9	54,4	64,1	72,2
Compressor power input	1	kW	8,5	10	12,1	13,5	16	19,4	22,3	25,5
Total power input	2	kW	9,06	10,5	12,61	15,2	17,7	21,1	24,1	27,3
EER	3		2,68	2,68	2,67	2,62	2,59	2,57	2,66	2,64
ESEER (EN 14511:21012)			3.63	3.63	3.62	3.46	3.42	3.40	3.72	3.70

COMPRESSOR

Type of compressors	4		SCROLL	SCROLL	SCROLL	SCROLL	SCROLL	SCROLL	SCROLL	SCROLL
No. of Compressors		Nr	2	2	2	2	2	2	2	2
Std Capacity control steps		Nr	3	3	2	3	3	3	3	2
Oil charge (C1)		l	3,61	3,72	3,54	5,76	5,76	6,65	7,39	8,28
Refrigerant charge (C1)		kg	8,2	8	11	12	12,5	15,5	17,5	17,5
Refrigerant circuits		Nr	1	1	1	1	1	1	1	1

INTERNAL EXCHANGER

Type of internal exchanger	5		PHE	PHE	PHE	PHE	PHE	PHE	PHE	PHE
No. of internal exchangers		Nr	1	1	1	1	1	1	1	1
Water flow rate (Internal Exchanger)	1	l/s	1,2	1,3	1,6	1,9	2,2	2,6	3,1	3,4
Max water flow-rate		l/s	1,5	1,8	2,3	2,7	3,1	4	4,6	5,4
internal exchanger pressure drop		kPa	48	47	41	43	43	38	40	42
Useful pump discharge head	1	kPa	132	126	120	104	88	148	139	131

EXTERNAL SECTION FANS

Type of fans	6		AX	AX	AX	AX	AX	AX	AX	AX
Number of fans		Nr	2	2	2	1	1	1	2	2
Standard air flow	1	l/s	2545	2538	2514	4933	4875	4778	7196	7145
Installed unit power		kW	0,27	0,27	0,27	1,94	1,94	1,94	2,06	2,06

CONNECTIONS

Water fittings			1" 1/4	1" 1/4	1" 1/4	2"	2"	2"	2"	2"
----------------	--	--	--------	--------	--------	----	----	----	----	----

HYDRAULIC CIRCUIT

Max water side pressure		MPa	0,55	0,55	0,55	0,55	0,55	0,55	0,55	0,55
Safety valve calibration		kPa	600	600	600	600	600	600	600	600

POWER SUPPLY

Standard power supply		V	400/3/50+	400/3/50+	400/3/50+	400/3/50+	400/3/50+	400/3/50+	400/3/50+	400/3/50+
-----------------------	--	---	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------

NOISE LEVELS

Sound pressure level (1 m)		dB(A)	60	60	60	64	64	65	65	65
----------------------------	--	-------	----	----	----	----	----	----	----	----

DIMENSIONS

Length		mm	1771	1771	1771	2012	2012	2012	2406	2406
Depth		mm	680	680	680	1100	1100	1100	1100	1100
Height		mm	1287	1287	1287	1599	1599	1599	1593	1593
Packing volume		m ³	1,8	1,8	1,8	4	4	4	4,5	4,5

STANDARD UNIT WEIGHTS

Shipping weight		kg	304	309	328	464	476	497	556	569
Operating weight		kg	298	303	323	456	469	490	547	561

(1) data referred to the following conditions :

internal exchanger water = 12/7°C

external exchanger air intake 35°C

(2) Total absorbed power is given by the compressor absorbed power + fan absorbed power + auxiliary circuit absorbed power.

(3) 100% EER

data referred to the following conditions :

internal exchanger water outlet temperature = 7°C

room temperature = 35°C

(4) SCROLL = scroll compressor

(5) PHE = plates

(6) AX = axial-flow fan

9 - TECHNICAL INFORMATION

OPERATING LIMITS (COOLING)


Size		82	102	122	162	182	222	262	302	
EXTERNAL EXCHANGER										
Max air intake temperature	1	°C	48	48,5	47	48,5	49	48,5	48,5	47,5
Max air intake temperature	2	°C	50	50,5	49	50,5	51	50,5	50,5	49,5
Min. air intake temperature	3	°C	-10	-10	-10	-10	-10	-10	-10	-10
INTERNAL EXCHANGER										
Max water inlet temperature	4	°C	23	23	23	23	23	23	23	23
Min. water outlet temperature	5	°C	5	5	5	5	5	5	5	5
Min. water outlet temperature	6	°C	-8	-8	-8	-8	-8	-8	-8	-8

Warning: the still air condition is meant as absence of air flow to the unit. Any wind condition can let air pass through the condenser coil thus worsening the operating limits of the unit (see limits with air speed at 0,5 m/s & 1 m/s).
 ATTENTION: IN CASE OF PREDOMINANT WINDS, WINDBREAK BARRIERS ARE NECESSARY.
 Water thermal head (min / max) are indicated in the section INTERNAL EXCHANGER PRESSURE DROP

capacity-controlled unit (automatic capacity control)
 (5) standard unit
 outdoor air temperature 35°C
 (6) B = Low Temperature
 outdoor air temperature 35°C
 Fluid with ethylene glycol of 40%

- (1) unit at full load: internal exchanger water 12/7°C
- (2) internal exchanger water = 12/7°C
capacity-controlled unit (automatic capacity control)
- (3) external exchanger air in quiet
- (4) this limit can be exceeded for brief and transitory periods with automatic capacity control of the unit: the maximum limit is 30°C.

INTERNAL EXCHANGER PRESSURE DROP



Size		82	102	122	162	182	222	262	302
Minimum flow	[l/s]	0.70	0.80	0.85	1.00	1.11	1.51	1.74	1.95
Maximum flow	[l/s]	1.52	1.80	2.85	2.71	3.05	4.05	4.65	5.00

9 - TECHNICAL INFORMATION

SOUND LEVELS

Size	Sound Power Level (dB)								Sound pressure level	Sound power level
	Octave band (Hz)									
	63	125	250	500	1000	2000	4000	8000	dB(A)	dB(A)
82	80	75	78	73	70	66	58	52	60	75
102	79	74	77	73	70	66	60	51	60	75
122	79	74	77	72	70	67	61	52	60	75
162	89	82	78	80	77	69	64	59	64	81
182	89	82	77	79	77	71	66	60	64	81
222	89	82	80	81	77	72	64	59	65	82
262	89	82	79	80	78	73	67	59	65	82
302	89	82	80	81	78	73	64	57	65	82

Measures according to ISO 9614-2 regulations, with respect to the EUROVENT 8/1 certification.

the sound levels refer to the unit at full load, in the rated test conditions.

The sound pressure level refers to a distance of 1m from the external surface of the units operating in an open field.

data referred to the following conditions :

internal exchanger water = 12/7°C

outdoor air temperature 35°C

CORRECTION FACTOR FOR ANTIFREEZE SOLUTIONS

% ethylene glycol by weight		5%	10%	15%	20%	25%	30%	35%	40%
Freezing temperature	°C	-2,0	-3,9	-6,5	-8,9	-11,8	-15,6	-19,0	-23,4
Safety temperature	°C	3,0	1,0	-1,0	-4,0	-6,0	-10,0	-14,0	-19,0
Cooling Capacity Factor	Nr	0,995	0,990	0,985	0,981	0,977	0,974	0,971	0,968
Compressor input Factor	Nr	0,997	0,993	0,990	0,988	0,986	0,984	0,982	0,981
Internal exchanger Glycol solution flow Factor	Nr	1,003	1,010	1,020	1,033	1,050	1,072	1,095	1,124
Pressure drop Factor	Nr	1,029	1,060	1,090	1,118	1,149	1,182	1,211	1,243

The correction factors shown refer to water and glycol ethylene mixes used to prevent the formation of frost on the exchangers in the water circuit during inactivity in winter.

10 - DECOMMISSIONING

9.1 DISCONNECTING

Only authorised personnel must disconnect the unit.

- Avoid leak or spills into the environment .
- Before disconnecting the unit, the following must be recovered, if present:
 - refrigerant gas
 - Anti-freeze solutions in the hydraulic circuit
- Awaiting dismantling and disposal, the unit can also be stored outdoors, as bad weather and rapid changes in temperature will not cause damage to the environment, if electric, cooling and hydraulic circuits of the unit are integral and closed.

9.2 DISMANTLING AND DISPOSAL

THE UNIT MUST ALWAYS BE SENT TO AUTHORISED CENTRES FOR DISMANTLING AND DISPOSAL.

When dismantling the unit, the fan, the motor and the coil, if operating, may be recovered by the specialist centres for reuse.

All the materials must be recovered or disposed of in compliance with the corresponding national standards in force.

For further information on the decommissioning of the unit, contact the manufacturer.

9.3 CE RAEE CE DIRECTIVE

The manufacturer is registered on the EEE National Register, in compliance with implementation of Directive 2012/19/EU and relevant national regulations on waste electrical and electronic equipment.

This Directive requires electrical and electronic equipment to be disposed of properly.

Equipment bearing the crossed-out wheellie bin mark must be disposed of separately at the end of its life cycle to prevent damage to human health and to the environment.

Electrical and electronic equipment must be disposed of together with all of its parts.

To dispose of "household" electrical and electronic equipment, the manufacturer recommends you contact an authorised dealer or an authorised ecological area.

"Professional" electrical and electronic equipment must be disposed of by authorised personnel through established waste disposal authorities around the country.

In this regard, here is the definition of household WEEE and professional WEEE:

WEEE from private households: WEEE originating from private households and WEEE which comes from commercial, industrial, institutional and other sources which, because of its nature and quantity, is similar to that from private households. Subject to the nature and quantity, where the waste from EEE was likely to have been by both a private household and users of other than private households, it will be classed as private household WEEE;

Professional WEEE: all WEEE which comes from users other

than private households.

This equipment may contain:

refrigerant gas, the entire contents of which must be recovered in suitable containers by specialised personnel with the necessary qualifications;

- lubrication oil contained in compressors and in the cooling circuit to be collected;
- mixtures with antifreeze in the water circuit, the contents of which are to be collected;
- mechanical and electrical parts to be separated and disposed of as authorised.

When machine components to be replaced for maintenance purposes are removed or when the entire unit reaches the end of its life and needs to be removed from the installation, waste should be separated by its nature and disposed of by authorised personnel at existing collection centres.



11 - RESIDUAL RISKS

11.1 GENERAL

In this section the most common situations are signalled. As these cannot be controlled by the manufacturer these could be a source of risk situations for people or things

11.2 DANGER ZONE

This is an area in which only an authorised operator may work. The danger zone is the area inside the unit which is accessible only with the deliberate removal of protections or parts thereof

11.3 HANDLING

The handling operations, if implemented without all of the protection necessary and without due caution, may cause the fall or the tipping of the unit with the consequent damage, even serious, to persons, things or the unit itself.

Handle the unit following the instructions provided in the present manual regarding the packaging and in compliance with the local regulations in force.

Should the gas refrigerant leak please refer to the refrigerant "Safety sheet".

11.4 INSTALLATION

An incorrect installation of the unit could cause water leaks, condensate accumulation, leaking of the refrigerant, electric shock, bad functioning or damage to the unit itself.

Check that the installation has been implemented by qualified technical personnel only and that the instructions contained in the present manual and the local regulations in force have been adhered to.

The installation of the unit in a place where even infrequent leaks of inflammable gas and the accumulation of this gas in the area surrounding the area occur could cause explosions or fires.

Carefully check the positioning of the unit.

The installation of the unit in a place unsuited to support its weight and/or guarantee adequate anchorage may cause the fall or the tipping of the unit with the consequent damage to things, people or the unit itself.

Carefully check the positioning and the anchoring of the unit. Easy access to the unit by children, unauthorised persons or animals may be the source of accidents, some serious.

Install the unit in areas which are only accessible to authorised person and/or provide protection against intrusion into the danger zone .

11.5 GENERAL RISKS

Smell of burning, smoke or other signals of serious anomalies may indicate a situation which could cause damage to people, things or the unit itself.

Electrically isolate the unit (yellow-red isolator).

Contact the authorised service centre to identify and resolve the problem at the source of the anomaly.

Accidental contact with exchange batteries, compressors, air

delivery tubes or other components may cause injuries and/or burns.

Always wear suitable clothing including protective gloves to work inside the danger zone.

Maintenance and repair operations carried out by non-qualified personnel may cause damage to persons, things or the unit itself.

Always contact the qualified assistance centre.

Failing to close the unit panels or failure to check the correct tightening of all of the panelling fixing screws may cause damage to persons, things or the unit itself.

Periodically check that all of the panels are correctly closed and fixed.

If there is a fire the temperature of the refrigerant could reach values that increase the pressure to beyond the safety valve with the consequent possible projection of the refrigerant itself or explosion of the circuit parts that remain isolated by the closure of the tap.

Do not remain in the vicinity of the safety valve and never leave the refrigerating system taps closed.

11.6 ELECTRICS PARTS

An incomplete attachment line to the electric network or with incorrectly sized cables and/or unsuitable protective devices can cause electric shocks, intoxication, damage to the unit or fires.

Carry out all of the work on the electric system referring to the electric layout and the present manual ensuring the use of a system thereto dedicated.

An incorrect fixing of the electric components cover may favour the entry of dust, water etc inside and may consequently can electric shocks, damage to the unit or fires. Always fix the unit cover properly.

When the metallic mass of the unit is under voltage and is not correctly connected to the earthing system it may be as source of electric shock and electrocution.

Always pay particular attention to the implementation of the earthing system connections.

Contact with parts under voltage accessible inside the unit after the removal of the guards can cause electric shocks, burns and electrocution.

Open and padlock the general isolator prior to removing the guards and signal work in progress with the appropriate shield.

Contact with parts that could be under voltage due to the start up of the unit may cause electric shocks, burns and electrocution.

When voltage is necessary for the circuit open the isolator on the attachment line of the unit itself, padlock it and display the appropriate warning shield.

11 - RESIDUAL RISKS

11.7 MOVING PARTS

Contact with the transmissions or with the fan aspiration can cause injuries.

Prior to entering the inside of the unit open the isolator situated on the connection line of the unit itself, padlock and display the suitable sign.

Contact with the fans can cause injuries.

Prior to removing the protective grill or the fans, open the isolator on the attachment line of the unit itself, padlock it and display the appropriate warning sign.

11.8 REFRIGERANT

The intervention of the safety valve and the consequent expulsion of the gas refrigerant may cause injuries and intoxication. Always wear suitable clothing including protective gloves and eyeglasses for operations inside the danger zone. Should the gas refrigerant leak please refer to the refrigerant "Safety sheet".

Contact between open flames or heat sources with the refrigerant or the heating of the gas circuit under pressure (e.g. during welding operations) may cause explosions or fires.

Do not place any heat source inside the danger zone.

The maintenance or repair interventions which include welding must be carried out with the system off.

11.9 HYDRAULIC PARTS

Defects in tubing, the attachments or the cut-off parts may cause a leak or water projection with the consequent damages to people, things or shortcircuit the unit.



CLIVET SPA

Via Camp Lonc 25, Z.I. Villapaiera - 32032 Feltre (BL) - Italy
Tel. + 39 0439 3131 - Fax + 39 0439 313300 - info@clivet.it

Clivet Group UK Limited

4 Kingdom Close, Segensworth East - Fareham, Hampshire - PO15 5TJ - United Kingdom
Tel. + 44 (0) 1489 572238 - Fax + 44 (0) 1489 573033 - enquiries@clivetgroup.co.uk

CLIVET ESPAÑA S.A.U.

C/ Bac de Roda, 36 - 08019 Barcelona - España
Tel: +34 93 8606248 - Fax +34 93 8855392 - info@clivet.es

Av.Manoteras N° 38, Oficina C303 - 28050 Madrid - España
Tel. +34 91 6658280 - Fax +34 91 6657806 - info@clivet.es

CLIVET GmbH

Hummelsbütteler Steindamm 84, 22851 Norderstedt - Germany
Tel. + 49 (0) 40 32 59 57-0 - Fax + 49 (0) 40 32 59 57-194 - info.de@clivet.com

CLIVET RUSSIA

Elektrozavodskaya st. 24, office 509 - 107023, Moscow, Russia
Tel. + 74956462009 - Fax + 74956462009 - info.ru@clivet.com

CLIVET MIDEAST FZCO

Dubai Silicon Oasis (DSO), High Bay Complex, Office N. 20, PO BOX 342009, Dubai, UAE
Tel. + 9714 3208499 - Fax + 9714 3208216 - info@clivet.ae

CLIVET AIRCONDITIONING SYSTEMS PRIVATE LIMITED

501/502, Commercial-1, Kohinoor City, Old Premier Compound, Kirol Road, Off L B S Marg, Kurla West - Mumbai
400 070 - India info.in@clivet.com